

This Quick Reference Guide includes short descriptions on how to use the basic functions. To learn more about all available functions, please see the related User Guide.

Dialog 4223 Professional Dialog 4225 Vision

System Telephones for MD110 Communication System *D4 Mode*

Quick Reference Guide

The complete User Guide is available in electronic format on the Telephone Toolbox CD and on http://www.ericsson.com/enterprise/library/manuals.shtml

Menu navigation (idle menus)

Dialog 4223 - To navigate: use Display menu keys. When a function is not shown in the display, press (more...) repeatedly until appearing.

n Missed CallList PhoneBook Absence Account Authority Lock LogOn/Off Timer Redial Program PhoneSet HideMenu

Dialog 4225 top menu - To navigate: use Navigation keys.

Program PhoneSet CallList PhoneBook Messages

Note: Some menu functions may only be available if you are authorized. The n Missed function is only shown when there are missed calls in the Call list.

Dialog 4225 low menu - To navigate: use Display menu keys. When a function is not shown in the display, press (more...) repeatedly until appearing

n Missed Absence Account Authority Lock LogOn/Off Timer Redial Hide/ShowMenu

Free Seating¹

Log on:

★ 1 1 ★ Authorization code ★

Own ext. No. #

Log off: #11# 📿

Answer Calls

Answer:

Handsfree: Press flashing Line key

On another

extension

(Call Pick-up): Call ringing ext. CallPickUp

End call: or or or

Make Calls

Internal calls: Ext. No.

External calls: External line code and No.

Handsfree: Dial No.

Individual Speed

Dialing number: $\times \times (0-9)$

Finland: * * (1 - 9); Sweden: (0 - 9) #

Dial by a function

key: Press the preprogrammed key, e.g.

Head office

Last External Number Redial:

umber Redial: Redial

Dial by phone book, example "Eva":

Dialog 4223: PhoneBook 33 Find Down or Up

Call

Dialog 4225: PhoneBook Select 33 Find

Down or Up Call

Redial calls from

the Call list: CallList Select Down or Up Call

or

n Missed Down or Up Call

Inquiry

Ongoing

conversation:

Inquiry Call 3rd party

Refer back: Line 1 or Inquiry

Line 1

Return to first

party and finish

Inquiry:

C

Transfer

Ongoing conversation:

Conf/Transf Call 3rd party

Transfer (Before or after answer)

Conference

Ongoing

conversation: Conf/Transf Call 3rd party

Conference (After answer)

Call Waiting

Activate: CallWaiting (At busy tone) Wait on line

Callback

Activate: CallBack

Cancel single Callback:

#37* Ext. No. #

Cancel all

Callbacks: #37#

Handsfree

From handset:



Back to handset:

Dialing during a connected call

Switch to DTMF: Tones Dial requested digits

On Hold

Individual: Line

Resume call: Line

Common hold: CommonHold

Resume call on

own ext.: Line

Resume call on

another ext.: Call the extension where the call was put

on hold CallPickUp

Personal Number¹

Activate: Absence Select Down or Up Select

Cancel: Absence Select Select

Diversion

Activate: Diversion or

Absence Down Activate

Cancel: Diversion or NoDiversion

Internal Follow-me

Order from your

own extension: Absence Down Select

New ext. No. Enter

Redirect from answering

position: \star 21 \star Own ext. No. \star

New ext. No. # U.K.: *2*

Cancel: # 2 1 * Own ext. No. #

U.K: #2 ×

Ericsson Enterprise AB. All rights reserved. Subject to alteration without prior notice. For more information, please contact your Ericsson Enterprise certified sales partner.

External Follow-me

Order: Absence Down or Up Select

External line code and No. Enter

Diversion or NoDiversion

Absence Information¹

Order: Absence Down Select

Down or Up Select

With return

Cancel:

date/time: Absence Down Select

Down or Up Select Date/Time Enter

Cancel: Diversion or NoDiversion

Programming of Function Keys

Program or

change: Program Select Press a function key

No. or Code Press function key again

Exit

Voice Mail¹

Enter your mailbox: Dial voice mail No. and follow recorded

instructions

New message

received: Message Follow recorded

instructions

Account Code¹

New external call: Account Account code Enter

External line code and No.

Ongoing external

call: Line Account Account code Enter

Line

Display Language¹

Change language: $\times 0.8 \times$ Language code (0-9) #

C

General Deactivation

Cancel all activated

features: #001# 📿

Abbreviations and Explanations

ext. Extension **n** Number of missed calls

No. Number 1 Optional

© Ericsson Enterprise AB 2004-04 EN Part of LZV 103 007

